


Panel Replacement

B: INSTALLATION

• Overall view (LH)



BS-06170


(1) 1 point (service)
(2) 6 points (service)

(3) 3 points

(4) 3 points (service)

Panel Replacement

- (RH)



BS-06172

(1) 4 points (service)


(2) 3 points (service)

(3) 2 points

Note: Designations in the RH diagram are the same as in the LH diagram, except for the indicated points.

Panel Replacement

• Views 1



(1) 2 points (service)

(3) 2 points


(4) 4 points (service)

(2) 1 point (service)

Note: Designations in the RH diagram are the same as in the LH diagram, except for the indicated points.

Panel Replacement

• Views 2



(1) 1 point (service)

(2) 5 points (service)

(3) 2 points (service)