


Panel Replacement

B: INSTALLATION



(1) 1 point
(2) 7 points

(3) 2 points
(4) 4 points

(5) 5 points

For locations marked by "★": the welding method and the number of welding points are the same on the left and the right.